

# ERD: Tutorials and Howtos

- [EFM Emerson ROC Quickstart](#)
  - Explains setting up the EFM Emerson ROC driver module and configuring the device connections
- [Sending ROC Alarms to a Central Ignition Gateway](#)
  - Explains how to get alarms to the central Ignition gateway.
- [Sending ROC Events to a Central Ignition Gateway](#)
  - Explains how to get events to the central Ignition gateway.
- [Sending ROC History to a Central Ignition Gateway](#)
  - Explains how to get history to the central Ignition gateway.
- [Emerson ROC Driver Configuration Data Storage](#)
  - Explains where the Emerson ROC Driver configuration is stored
- [Tips for debugging Emerson ROC TLP configuration issues](#)
  - Provides tips for debugging Emerson ROC TLP configuration issues
- [Cloning an Emerson ROC Device Connection](#)
  - Details scripts to clone an Emerson ROC Device Connection