

Configuring Secure MQTT Communication

MQTT Distributor can be enabled to use TLS to encrypt the communication between MQTT clients. This is useful if MQTT Distributor is used on a public network. Since MQTT communications are not encrypted by default, enabling TLS is highly recommended on a public network.

Reusing Ignition SSL Certificates


As of module release version [3.4.7](#), the Cirrus Link MQTT Distributor module is capable of reusing the existing Ignition web server SSL certificates to secure your MQTT communication. This is the recommended process to secure your MQTT communication using SSL/TLS. If using modules versioned before 3.4.7, the details [here](#) will help you through this process.

SSL/TLS Enable the Ignition Web Server

Follow the steps outlined [here](#) to SSL enable the Ignition Web Server.

Configure MQTT Distributor to use SSL/TLS

Once the Ignition Web Server has been SSL enabled, enable SSL/TLS for MQTT Distributor by checking the "Enable TLS" configuration setting under ConfigMQTT DistributorSettingsGeneralTLS Settings. Click Save to confirm the configuration update.



Configure MQTT Engine and Transmission to use SSL/TLS

Once TLS has been enabled for MQTT Distributor, the only change required* for MQTT Engine and MQTT Transmission to connect to Distributor over SSL/TLS, is to update the MQTT Server URL. Update the following MQTT Server URL configuration settings with the appropriate MQTT Server URL for your environment. For example, 'ssl://mqttserver:8883'

SSL/TLS Configuration Settings:

- ConfigMQTT EngineSettingsServers->Settings[Edit:Your MQTT Server]MainURL
- ConfigMQTT TransmissionSettingsServers->Settings[Edit:Your MQTT Server]MainURL

The screenshot below shows MQTT Transmission configured for SSL/TLS. Configure MQTT Engine to use SSL/TLS in the same way.

The screenshot shows the 'Edit MQTT Server' configuration page in the Ignition Gateway web interface. The left sidebar contains a navigation menu with categories like Modules, Networking, Security, Databases, Alarming, Tags, OPC-UA Server, OPC Connections, Mobile, Enterprise Administration, Sequential Function Charts, and Settings. The main content area has tabs for General, Servers, Sets, Transmitters, and Records. The 'Certificates' sub-tab is active, showing a form for configuring an MQTT server. The form includes fields for Name, URL, Server Type, Server Set, Username, Change Password?, Password, and a CA Certificate File dropdown. The 'Server Type' is set to 'MQTT_Distributor' and the 'CA Certificate File' is set to '- none -'.

Main	
Name	Distributor MQTT Server The friendly name of this MQTT Server
URL	ssl://localhost:8883 The URL of the MQTT Server to connect to. Should be of the form tcp://mydomain.com:1883 or ssl://mydomain.com:8883
Server Type	MQTT_Distributor The type of MQTT Server to connect to (default: MQTT_Distributor)
Server Set	Default The Server Set this MQTT Server is associated with
Username	admin The username for this MQTT connection if required by the MQTT Server (optional)
Change Password?	<input type="checkbox"/> Check this box to change the existing password.
Password	<input type="password"/> The password for this MQTT connection if required by the MQTT Server (optional)
Password	<input type="password"/> Re-type password for verification.

TLS	
CA Certificate File	- none - CA Certificate file currently in use


At this point, MQTT Engine and MQTT Transmission should show they're connected to MQTT Distributor over SSL/TLS.

The screenshot shows the 'MQTT Transmission Settings' page in the Ignition Gateway web interface. The left sidebar is the same as the previous screenshot. The main content area has tabs for General, Servers, Sets, Transmitters, and Records. The 'Servers' sub-tab is active, showing a table of MQTT servers. The table has columns for Name, URL, Server Type, Server Set, Username, CA Certificate File, and Connected. There is one entry: 'Distributor MQTT Server' with URL 'ssl://localhost:8883', Server Type 'MQTT_Distributor', Server Set 'Default', Username 'admin', and Connected '1 of 1'. There are 'delete' and 'edit' buttons for this entry. Below the table is a link to 'Create new MQTT Server...'. A note at the bottom states: 'Note: For additional details on configuring MQTT Transmission, see the documentation here'.

Name	URL	Server Type	Server Set	Username	CA Certificate File	Connected
Distributor MQTT Server	ssl://localhost:8883	MQTT_Distributor	Default	admin		1 of 1

[Create new MQTT Server...](#)

Note: For additional details on configuring MQTT Transmission, see the documentation [here](#)



If running pre-3.4.7 modules, your Ignition web server is not SSL/TLS enabled, you're [using self-signed certificates](#) or the [default workflow](#) above did not work as expected, read on to see [notes](#) and [variations](#) on the standard process for enabling SSL/TLS.

Configuration Variations

Using a Java Keystore File with Distributor

This step should only be necessary if you're running pre-3.4.7 modules. The steps below will show how to create a Java keystore (JKS) containing all appropriate certificates and how to configure MQTT Distributor to use this keystore.

Convert Ignition's Keystore

If running pre-3.4.7 modules and your Ignition web server **is** SSL/TLS enabled, you can create the necessary Java keystore (JKS) file from the existing Ignition keystore (<Ignition_Install>\webserver\ssl.pfx). This can be done easily using the KeyStore Explorer tool to convert the Ignition keystore of type PKCS #12 to a Java keystore of type JKS. The details [here](#) will help you through this process.

Create a Java Keystore

If running pre-3.4.7 modules and your Ignition web server **is not** SSL/TLS enabled, you will need to create a Java keystore from scratch using the KeyStore Explorer tool. The details [here](#) will help you through this process.

Using Self-signed Certificates


If using self-signed certificates in your environment, the steps to enable SSL/TLS are identical to the [default workflow](#) with the additional requirement that the certificate chain (aka. "chain-of-trust") be available to MQTT Engine and Transmission. When using self-signed certificates, the required CA certificates are not known to MQTT clients by default as they would be if the certificate was generated by a real CA and the CA certificate was provided by Java's [default keystore](#). Therefore, MQTT Engine and Transmission must be configured to use the appropriate certificate chain.

Identify the certificate chain


The certificate chain (aka. "chain-of-trust") is a collection of the public root CA (Certificate Authority) certificate and any/all public intermediate CA certificates between the root and the CA that issued the certificate. If there are no intermediate CAs, then the chain is made up of only the public root CA certificate. You will need to configure MQTT Engine and Transmission to trust these CAs by adding their certificates under MQTT Engine and MQTT Transmission configuration. If a single certificate, move to the next step to upload and configure this certificate. If more than one certificate makes up the certificate chain, you will need to copy the contents of each certificate into a single file (in x509 PEM format; give it a name like 'ca-chain.cert.pem') and move to the next step to upload then configure this certificate.

Upload the certificate chain

To upload the certificate chain (aka. "chain-of-trust") to MQTT Engine and MQTT Transmission, launch the Ignition Web Portal, navigate to the "Servers" tab in the module configuration for each module, click on the "Certificates" tab and click 'Create new Certificate' to bring up the creation UI. Next, choose the certificate to upload, give it a friendly name like 'CaChain' and click 'Save'. The two screenshots below show configuration specific to MQTT Transmission. Configure MQTT Engine certificates in the same way.



Associate the certificate just uploaded to each module by setting the 'CA Certificate File' configuration setting to be equal to the certificate created. Click 'Save'.



MQTT Engine and Transmission should now [show connected](#) to Distributor over SSL/TLS. If the connection is unsuccessful, review the steps in the [default workflow](#) to ensure they were completed successfully.

Notes

Getting a Certificate from a Certificate Authority

The first step to securing MQTT communication is to get a certificate from a certificate authority (CA). There are many available such as Verisign, Thawte and RapidSSL. There are also a number of other certificate authorities available. The general process is as follows:

- Generate a RSA key
 - This is the private key and used for encryption/decryption of data. Keep this private and don't share it with anyone including the CA. However, the server (MQTT Distributor) will need it to encrypt/decrypt data.
- Create a Certificate Signing Request (CSR)
 - Generally the CA can provide instructions on how to generate a CSR. Windows, Linux, and OSX all have tools available for generating a CSR and there is lots of documentation online about all of them.
 - Make sure the Common Name specified in the CSR matches the server URL (i.e. [example.com](#)). Also, do not include www. because this will be used for MQTT.
- Give the CSR to the CA
- The CA will then provide back a public certificate for use with MQTT Distributor
- In some cases depending on the CA an intermediate certificate may also be required. If so, the CA will also provide this.

Creating a Self-Signed Certificate

Creating your own CA, intermediate CA, and generating your own signed certificates can be done following the three steps below using some open source tooling. Note creating an Intermediate CA is not explicitly required, but is recommended if you will be using self-signed certs in a private network in production. If this is simply for development that step can be skipped and the root CA can be used to sign server certificates. Again, using self-signed certs in production over the Internet is not recommended.

- [Create the Root Pair](#)
- [Create and Sign the Intermediate Pair](#)
- [Create and Sign the Server pair](#)
 - Make sure the Common Name specified in the CSR matches the server URL that will be used by the clients (i.e. 192.168.1.100). It could also be the network hostname.