

# Cirrus Link Documentation

Welcome to the home of Cirrus Link Solutions documentation!

In this manual, you will find reference information along with step-by-step tutorials. The final goal of the content and information provided here is to help you gain understanding in regards to enabling the Cirrus Link MQTT Modules for Ignition so that you can create MQTT Message Oriented Middleware solutions on the Ignition Application Platform. In addition, the Cirrus Link Cloud Modules can be used to push any Ignition tag data to big data platforms such as Microsoft's Azure and Amazon's AWS.

The table of content is organized so you can easily find answers to your questions on all the features on the modules. Some of the things you will learn in this manual are: how to install and configure the software, enable Ignition to be MQTT aware, enabled Ignition to connect to bug data platforms, and reference information on MQTT.

Let's **GET STARTED!**