

Opto 22 groov EPIC and SNAP PAC Driver

The Opto 22 *groov* EPIC and SNAP PAC Driver module is an Ignition driver for accessing Tags directly from Opto 22 groov EPIC and SNAP PAC™ controllers.

The driver supports all *groov* EPIC and SNAP PAC controllers and SoftPAC™ software-based controllers with PAC firmware R9.2c or higher

More information including installation instructions can be found in the links below.

- [Cirrus Link Module Installation](#)
 - Step by step instructions to install modules into Ignition
- [Opto 22 groov EPIC and SNAP PAC Module Configuration](#)
 - Configuration guide for the Opto 22 module
- [Opto 22 groov EPIC and SNAP PAC Tutorials / HowTo's](#)
 - Tutorials and howtos covering installation, configurations, and usage of Opto 22 module
- [Opto 22 groov EPIC and SNAP PAC Module Videos](#)
 - Videos for installing and configuring the Driver module