

ERD: Tutorials and Howtos

- [EFM Emerson ROC Backup Procedure](#)
 - Covers the gateway backup/restore process if using EFM Emerson ROC Module v3.4.9 or earlier. This is not required if running v3.4.10 or later.
- [EFM Emerson ROC Quickstart](#)
 - Shows basic setup of the EFM Emerson ROC Driver
- [Sending ROC Alarms to a Central Ignition Gateway](#)
 - Shows how to configure the EFM Emerson ROC Driver to send *Alarm* records to a central Ignition Gateway
- [Sending ROC Events to a Central Ignition Gateway](#)
 - Shows how to configure the EFM Emerson ROC Driver to send *Event* records to a central Ignition Gateway
- [Sending ROC History to a Central Ignition Gateway](#)
 - Shows how to configure the EFM Emerson ROC Driver to send *History* records to a central Ignition Gateway