

# Configuration Reference

- [Cloud Modules](#)
  - [AWS Injector Configuration](#)
    - Configuration options for the AWS Injector module
  - [Azure Injector Configuration](#)
    - Configuration options for the Azure Injector module
  - [Google Cloud Injector Configuration](#)
    - Configuration options for the Google Cloud Injector module
  - [IBM Cloud Injector Configuration](#)
    - Configuration options for the IBM Cloud Injector module
- [MQTT Modules](#)
  - [MQTT Distributor Configuration](#)
    - Configuration options for the MQTT Distributor module
  - [MQTT Engine Configuration](#)
    - Configuration options for the MQTT Engine module
  - [MQTT Transmission Configuration](#)
    - Configuration options for the MQTT Transmission module
  - [MQTT Recorder Configuration](#)
    - Configuration options for the MQTT Recorder module
- [Driver Modules](#)
  - [Emerson ROC Driver Configuration](#)
    - Configuration options for the EFM Emerson ROC Driver module
  - [Opto 22 groov EPIC and SNAP PAC Driver Configuration](#)
    - Configuration options for the Opto 22 groov EPIC and SNAP PAC Driver module